

## 9. Control Channel

### 9. 1DMX control channel

5CH	6CH	11CH	Channel Description
1	1	1	R dimmer
2	2	2	G dimmer
3	3	3	B dimmer
4	4	4	W dimmer
—	—	5	Color Temp
—	—	6	Macro color
—	—	7	Strobe
—	—	8	Soft light fading
—	—	9	Color cycling
—	5	10	Dimmer
5	6	11	Zoom

### 9.2DMX channel feature

11CH	Channel Description	DMX value	DMX dimmer description
1	R	0-255	0-100% R dimmer
2	G	0-255	0-100% G dimmer
3	B	0-255	0-100% B dimmer
4	W	0-255	0-100% W dimmer
5	Color Temp	0	No function
		1-255	8000K-2700K
6	Macro color	0-9	No function
		10-255	Color macro effect
7	Strobe	0-7	No function
		8-255	Strobe, slowly fast, 1Hz-25Hz
8	Soft light fading	0	No function
		1-255	Soft light fading, slowly fast
9	Color cycling	0	No function
		1-255	cycling, slowly fast
10	Dimmer	0-255	0-100% dimmer
11	Zoom	0-255	Spot size, small fast

ATTN: This channel is for FINE 1514 ZOOM. If for FINE 1514DG, "ZOOM" function is excluded.